

UTENSILI DA CUCINA
COOKING UTENSILS





RPM100



RPS220



RPS200

RPM100

PINZA CUCINA

30,9 cm

h. 4,8 cm

KITCHEN PINCER

12,16 inch

h. 1,89 inch

RPS200

PALA RISO

28,6 cm

h. 8 cm

RICE SHOVEL

11,25 inch

h. 3,15 inch

RPS220

PALA LASAGNA

29 cm

h. 8 cm

LASAGNA SHOVEL

11,41 inch

h. 3,15 inch